



INSET OVEN CABINET


1.




2.




3.




4.




5.




6.




7.




8.




9.




10.



11.




12.




13.


Hinge installation and adjustment




Click and lock




Click and remove



Side adjustment




Up&down adjustment




Depth adjustment


14.



15.




16.




Put the adjusting part back and tighten the screws.

17.




Lay the drawer bottom onto the slide then push the drawer into the cabinet.

18.




Up&Down adjustment.

19.




Side adjustment.

20.




Depth adjustment.

21.




Removal.

22.




INSET TALL PANTRY CABINET


1.




2.




3.




4.




5.




6.




7.



8.




9.




10.


Hinge installation and adjustment




Click and lock




Click and remove



Side adjustment



Up&down adjustment



Depth adjustment

11.

