



INSET WALL CABINET




9.




10.


Hinge installation and adjustment




Click and lock




Click and remove



Side adjustment




Up&down adjustment




Depth adjustment


Glass Door




INSET WALL DIAGONAL CABINET




7.




8.




9.




10.




11.




12.



13.




14.




15.


Hinge installation and adjustment




Click and lock




Click and remove



Side adjustment




Up&down adjustment




Depth adjustment


INSET WALL EASY REACH CABINET




7.




8.




9.




10.



11.




12.




13.


Hinge installation and adjustment




Click and lock



Click and remove



Depth adjustment



Side adjustment